

# Y-Box LED indications

		No power / idle	
		Waiting for USB enumeration	] Abnormal if permanent
		Waiting for DFU (1–2 s)	
		rkill active (also disables USB)	
		RF activity	
		CC2543 (RF) panic	] Abnormal conditions
		KL26 (USB) panic	
		CC2543 debug not responding	
		Firmware not responding	

	LED is off		Slow blink
	LED is on (continuously)		Fast blink
	LED can be in any state		Brief flashes